



- 30. 조명사다리 4 (#4 LIGHTING LADDER)
- 29. 조명사다리 3 (#3 LIGHTING LADDER)
- 28. 조명사다리 2 (#2 LIGHTING LADDER)
- 27. 조명사다리 1 (#1 LIGHTING LADDER)

- 26. 검정하늘막 (BLACK CYCLORAMA)
- 25. 하늘막 (CYCLORAMA)
- 24. 장치봉 8 (#8 SET BATTEN)
- 23. 장치봉 7 (#7 SET BATTEN)
- 22. 장치봉 6 (#6 SET BATTEN)
- 21. 하늘막상단조명 + 머리막 2 (UPPER CYC.LIGHT + #2 HOUSE BORDER)
- 20. 조명봉 3 (#3 LIGHT BATTEN)
- 19. 후면음향반사판 (ACOUSTICAL SHELL-BACK WALL)
- 18. 장치봉 5 (#5 SET BATTEN)
- 17. 끝막 2 + 머리막 1 (#2 DRAW CURTAIN + #1 HOUSE BORDER)
- 15,16. 측면음향반사판 3,4 (#3,4 ACOUSTICAL SHELL-SIDE WALL)
- 14. 천장음향반사판 2 (#2 ACOUSTICAL SHELL-CEILING)
- 13. 장치봉 3 (#3 SET BATTEN)
- 12. 장치봉 2 (#2 SET BATTEN)
- 11. 조명봉 2 (#2 LIGHT BATTEN)
- 10. 영사막 (SCREEN)
- 09. 끝막 1 (#1 DRAW CURTAIN)
- 08. 300"영사막 (300"SCREEN)
- 07. 장치봉 2 (#2 SET BATTEN)
- 05,06. 측면음향반사판 1,2 (#1,2 ACOUSTICAL SHELL-SIDE WALL)
- 04. 천장음향반사판 1 (#1 ACOUSTICAL SHELL-CEILING)
- 03. 장치봉 1 (#1 SET BATTEN)
- 02. 조명봉 1 (#1 LIGHT BATTEN)
- 01. 면막 (HOUSE CURTAIN)
- 00. 영점선 (ZERO LINE)
- 01. 앞무대조명 (APRON LIGHT)
- 02. 현수막봉 (PLACARD BATTEN)